

## Test Procedure for the NCP2993FCT2GEVB Evaluation Board

## **Output Power:**

- 1. Set Vp = 5V to power supply connector (J1).
- 2. Set an  $8\Omega$  load (resistance) on the output connector (J5).
- 3. With the function generator, set a single ended signal at 1kHz and 0.5Vrms input signal on the negative input. Apply this signal either on the J2 or J3 connector. As R1=R2=24k, VO1 will see 0.5Vrms. As VO1 signal is inverted by the second amplifier, VO2 will also see 0.5Vrms with 180° delay. Thus, the load between VO1 and VO2 will see 1Vrms.
- 4. Place 2 oscilloscope probes on the output (differential measurement). You should get 1Vrms output signal with a "perfect sine wave". That is to say no clipping at the minima and maxima of the sine wave.

## **Quiescent Current**:

Check the quiescent current. Place an  $8\Omega$  load, no input signal. Vp set to 5V and J6 closed. You should measure around 1.9mA.

10/21/2011 - 1 - www.onsemi.com